



Instruction I-220a
for S/N 80550 and later

**INSTALLATION, OPERATION, AND
MAINTENANCE INSTRUCTIONS
FOR
MODEL WKM HIGH PRESSURE
MULTIPLE STAGE CENTRIFUGAL PUMPS**

CARVER PUMP COMPANY
2415 Park Avenue • Muscatine, Iowa 52761-5691
Phone (563) 263-3410 • Main Fax (563) 262-0509
Marketing Fax (563) 262-0510
E-Mail: carverpump@muscanet.com
WEB: www.carverpump.com



TABLE OF CONTENTS

Section/Paragraph	Page
I. General Information	1
A. Preface	1
B. Pump Identification	1
C. Safety Precautions	1
D. Equipment Description	1
E. Method of Operation	2
F. Handling	2
G. Inspection	2
H. Factory Repair	2
II. INSTALLATION	2
A. Foundation and Mounting	2
B. Coupling Alignment	2
C. Grouting	4
D. Piping Installation	4
E. Auxiliary Connections	5
III. OPERATION	5
A. Prestart Cautions	5
B. Start Up	5
C. Stopping the Pump	8
D. Operating Checks	8
IV. TROUBLESHOOTING	9
V. MAINTENANCE	11
A. Maintenance of Bearings	11
B. Packing Pumps, Stuffing Box Maintenance	11
C. Driver Maintenance	11
D. Indefinite Shutdown	12
VI. DISASSEMBLY AND REASSEMBLY	12
A. Recommended Tools	12
B. Preparations for Disassembly	12
C. Disassembly	12
D. Parts Cleaning and Inspection	14
E. Wear Ring Replacement	14
F. Preparations for Reassembly	15
G. Reassembly	15
H. Axial Alignment of Rotor	18
I. Packing Pumps, Packing Removal and Installation	20
VII. SPARE PARTS	20
VIII. TECHNICAL DATA	20
IX. PARTS LIST AND DRAWINGS	20
X. PUMP SERVICE RECORD	35

LIST OF TABLES

Number	Title	Page
1.	Minimum Flow Rates	5
2.	Cooling Water Flow Rates	8
3.	Troubleshooting	9
4.	Maximum Wear Ring Clearance for Allowable Wear.....	14
5.	New Wear Ring Clearance Limits.....	15
6.	Recommended Torque Values	15
7.	Mechanical Seal Settings	16
8.	Axial Alignment Control Dimensions.....	20
9.	Recommended Spare Parts	21
10.	Specifications and Operating Limits	21
10A.	Recommended Oil Types for Bearing Lubrication.....	21
11.	Parts List.....	22

LIST OF ILLUSTRATIONS

Number	Title	Page
1.	Internal View and Flow Pattern of Heat Exchanger.....	3
2.	Coupling Alignment.....	4
3.	Grouting Baseplate	4
4.	WKM Piping Plans.....	6
5.	Trico Type E Oiler, Catalog Number 30054.....	7
6A.	Mechanical Seal, WKM-50 and WKM-65 Standard Design.....	17
6B.	Mechanical Seal, WKM-80 Standard Design.....	17
7A.	Axial Alignment of Rotor, WKM-50 and WKM-65	19
7B.	Axial Alignment of Rotor, WKM-80	19
8.	WKM High Temperature Design with Mechanical Seal Detail Drawing.....	24
9.	WKM High Temperature Design with Packing Detail Drawing	25
10.	WKM-50 and WKM-65 with Mechanical Seal Sectional Drawing.....	27
11.	WKM-50 and WKM-65 with Packing Sectional Drawing.....	29
12.	WKM-80 with Mechanical Seal Sectional Drawing	31
13.	WKM-80 with Packing Sectional Drawing.....	33

I. GENERAL INFORMATION.

A. Preface.

Carver Pump Company products are carefully engineered and manufactured, if properly installed, maintained, and operated, they should provide maintenance free operation and a long service life.

This manual is designed to provide sufficient material to properly maintain the WKM pump. The information as presented should improve your knowledge and understanding of the WKM pump, thus upgrading the quality of pump maintenance and care. Follow instructions in this manual carefully. Factory warranty applies only when pump operates under conditions as specified on our order acknowledgment and if pump is properly installed and maintained as recommended herein. A copy of these instructions should be available to operating personnel.

Variations exist in both the equipment used with these pumps and in particular installation of the pump and driver. Therefore, specific operating instructions are not within the scope of this manual. This manual contains general rules for installation, operation, and maintenance of the pump.

B. Pump Identification.

Use the following example for identifying information about your pump model number from the nameplate. A nameplate is attached to each pump. Nameplate data should be furnished to Carver Pump Company or its representative when ordering spare parts or requesting information.

C. Safety Precautions.

This manual contains descriptions and instructions for installation, operation, and maintenance of your WKM pump. The pump is of sturdy design and is constructed to give satisfactory service for a long period of time when the instructions outlined in this manual are followed. Failure or neglect to properly install, operate or maintain your pump may result in personal injury, property damage, or unnecessary damage to the pump.

The instructions in this manual are intended for personnel who possess general training in the operation and maintenance of centrifugal pumps. This information does not relieve personnel of the responsibility of exercising normal good judgment in operating and maintaining the pump and its components. All personnel should be guided by basic rules of safety associated with the equipment and the process.

Observe all warning, caution or danger tags attached to the equipment or included in this manual.

CAUTION

IMPORTANT SAFETY NOTICE

The installation, use, and operation of this type of equipment is affected by various federal, state, and local laws and the regulations concerning OSHA. Compliance with such laws relating to the proper installation and safe operation of this type of equipment is the responsibility of the equipment owner and all necessary steps should be taken by the owner to assure compliance with such laws before operating the equipment.

D. Equipment Description.

Refer to figure 8, 9, 10, 11, 12, or 13 as applicable. WKM high pressure pumps are multi-stage centrifugal pumps with vertically split casings. WKM pumps consist of the following models WKM-50, WKM-65, and WKM-80. The models available as mechanical seal pumps and packing pumps. The models are available in standard design and high temperature design for pumps operating between 220 to 285 degrees F.

The casing consists of suction and discharge casings (203 and 197), plus a number of interstage casings (1), all secured with tie bolts (173). Diffusers (5A and 5B) are inserted in individual stage casings (1).

Individual stage casings (1) are sealed by o-rings (89D). Suction and stage casings (203 and 1) are provided with wear rings (7A and 7B) which can be replaced if, after prolonged operation, wear has become excessive. Standard design, the bearing housing (99) is attached to the suction casing (203) by bolts (600). High temperature design, the bearing housing (99) and cooling jacket (215) are attached to the suction casing (203) by studs (632) and nuts (618).

The pump shaft (6) is protected against corrosion from fluid pumped and wear from rotating parts by interstage sleeves, sleeve spacers, and shaft sleeves. Impellers (2A and 2B) are secured on pump shaft (6) by keys (part numbers 32A and 32C on WKM-50 and WKM-65, 32A on WKM-80); all impellers (2A and 2B) face the same direction on the shaft (6).

The Timken two-row tapered roller bearing (16), type TDO, contains a double cup with two single cones and a cone spacer. The heat generated by the tapered roller bearing's surface contact necessitates cooling of the oil. On standard design pumps operating at temperatures below 85 degrees F, fluid pumped if used as coolant. Coolant to the bearing is supplied from an outside source on standard design pumps operating at temperatures above 85 degrees F and on high temperature design pumps.

WKM high pressure pumps incorporate special design refinements which help to absorb the appreciable axial thrust generated by their high head operation. Residual axial thrust is absorbed by the tapered roller bearing.

Mechanical seal pumps, the mechanical seal stops leakage along the shaft at the suction casing's stuffing box. Standard mechanical seals include John Crane Type 1 and Pac-Seal Type 21.

Packing pumps, the packing rings control leakage along the shaft at the suction casing's stuffing box.

High Temperature Design Pumps. Refer to figure 8 or 9. If pumped fluid is at operating temperatures between 220 to 285 degrees F, pumps of high temperature construction are used. These are provided with cooling jackets (215). Cooling jacket (215) separates suction casing (203) and bearing housing (99). Cooling water flows through cavities of cooling jacket (215) and keeps temperature at the stuffing box within acceptable limits.

Cooling lines are equipped with dual heat exchangers to reduce temperature of hot fluid pumped, pumped fluid may serve to cool the bearing and seal or stuffing box. Refer to figure 1 for an internal view and flow pattern of the heat exchanger.

NOTE

Even when using clean, fresh water as coolant, a periodic cleaning of cooling water cavities is recommended. Sediment and lime deposits seriously affect rate of heat transfer and will impair effective cooling.

Cooling water should flow freely and visibly so that its temperature and flow rate can be checked periodically. Temperature differential between cooling water inlet and outlet should not exceed 18 degrees F. The cooling water supply lines should be provided with valves to enable flow adjustment as required and shut-off when cooling water cavities are to be cleaned or when the pump is shut down.

E. Method of Operation.

Pumped fluid enters suction casing (203) and passes into first stage impeller (2A), which propels fluid into first stage diffuser (5A). The fluid then flows into the next impeller (2B). This process is repeated from one stage to the next, and at each stage fluid pressure increases by the same increment (this is termed "stage head"). After leaving final stage diffuser (5B), fluid enters discharge casing (197) and passes into discharge piping.

F. Handling.

CAUTION

To lift pumping unit, a hoist or suitable lifting device should be used. Do not pick up the complete unit by the driver or pump shafts or driver lifting eyes.

Complete pump set must be handled with care. Do not pass lifting slings through eye bolt on motor. Pump is shipped with flange covers to protect flange faces and to prevent foreign matter from entering pump. Flange

covers should remain intact until suction and discharge piping are connected to pump flanges.

G. Inspection.

Upon receipt of the shipment, unpack, and inspect the pumping unit, and individual parts to insure none are missing or damaged. Carefully inspect all boxes and packing material for loose parts before discarding them. Immediately report any missing parts or damage incurred during shipment to the factory and to the transportation company and file your "damaged and/or lost in shipment" claim with the carrier.

H. Factory Repair.

CAUTION

When pump is handling hazardous fluid, extreme care must be taken to ensure safety of personnel when attempting to drain pump. Suitable protection devices should be used and/or protective clothing should be worn.

If pump is sent back to Carver Pump Company factory for repair, it must be drained and all flanges and connections covered or plugged. Ship pumps in assembled condition to prevent damage to sealing faces of individual components.

II. INSTALLATION.

A. Foundation and Mounting.

CAUTION

To lift pumping unit, a hoist or suitable lifting device should be used. Do not pick up the complete unit by the driver or pump shafts or driver lifting eyes.

The foundation must be rigid and set on firm underground to absorb vibration and forces and moments without yielding. Ensure that concrete foundation has set hard before mounting pump set (pump and driver with baseplate). Surface of foundation must be horizontal and perfectly even.

If anchor bolts have not been preset in foundation, mark location of bolt holes in baseplate on foundation and drill appropriate holes. Suspend anchor bolts from baseplate. Place and thoroughly level baseplate on foundation by using shims or metal wedges. Shims must be fitted in close proximity to left and right of foundation bolts. If spacing between adjoining holes exceeds 30 inches, shims should be fitted halfway between holes. All shims must lie perfectly flush.

B. Coupling Alignment.

A pump or any rotating equipment will not be aligned after transport and installation, regardless of pre-alignment at factory. Pumping unit must be realigned before




Figure 1. Internal View and Flow Pattern of Heat Exchanger

and after grouting of baseplate and connection of suction and discharge piping. Before attempting any work on pump set, refer to safety precautions set forth in section I, paragraph C. Align pump and driver as follows:

1. Remove coupling guard.
2. Remove nuts and lockwashers from motor hold down bolts. Reinstall nuts only and finger tighten.
3. Disconnect coupling halves by removing flexible component from coupling.
4. Connect wiring to driver.
5. Bump start driver and verify that rotation is correct. Correct pump rotation is indicated by an arrow on the pump casing. The standard direction of rotation, viewed from the driver end is clockwise.
6. Tag out and lock power to driver according to OSHA Standard 1910.147.
7. Axial alignment of coupling is checked with a straight edge across both coupling halves, refer to figure 2. Measure distance A or B between straight edge and both shafts. Repeat measuring at two locations, 120 degrees apart, on periphery of coupling. The difference between three measurements for A and for B must not exceed 0.005 inch at any of the three positions.




Figure 2. Coupling Alignment

8. Angular alignment of coupling is checked with a feeler gauge, refer to figure 2. Measure distance between faces of both coupling halves, near their outside, on four locations spaced 90 degrees apart. The four measurements must be within ± 0.005 inch tolerance. The same tolerance applies if a dial indicator is used to check angular alignment. Fix dial indicator to one coupling half and take readings while other coupling half is rotated 360 degrees.

9. If coupling halves are misaligned, make adjustments on the driver end of the pumping unit. Make necessary adjustments by tapping motor housing with rawhide or wood mallet and shimming.
10. Repeat steps 7 through 9 until proper alignment is achieved.
11. Reinstall lockwashers and tighten nuts on motor hold down bolts.
12. Reconnect coupling by reinstalling the flexible component on coupling. Reinstall coupling guard.

C. Grouting.

When the unit has been leveled and coupling alignment is complete, the unit should be grouted using a high grade non-shrinking grout, refer to figure 3 and follow the following procedure:




Figure 3. Grouting Baseplate

1. Build a wooden dam around baseplate to retain the grout.
2. Pour grout through grouting holes provided in baseplate until entire space under baseplate is filled, with no voids or air pockets.
3. Insert a stiff wire through the grouting holes to work the grout and release any air pockets.
4. After the grout has hardened (72 hours) remove the dam and also the shims or wedges under the baseplate, if desired. Fill the holes left by the shims with grout.
5. Tighten foundation bolts loosely. Allow the grout to fully cure before firmly tightening the foundation bolts.
6. Recheck coupling alignment according to section II, paragraph B.

D. Piping Installation.

All piping must be arranged and, if necessary, supported so that no undue stress from piping weight is placed upon pump. Do not force piping. Never use pump as an anchorage point for the piping.

CAUTION

Extreme care should be taken when connecting new piping to see that no foreign matter such as dirt, slag, chips, tools, etc., are in piping as this debris will be drawn into pump and cause excessive damage. During initial installation and testing, a strainer should be installed in suction piping to keep debris from entering pump.

Suction lift lines should be laid with a rising slope toward pump and positive suction head lines should be laid with a downward slope toward pump to avoid air pocket formation. Suction piping must be at least the same size as pump suction nozzle. Compensation for heat elongation must be provided where required.

The coupling alignment must be rechecked as outlined in section II, paragraph B after installation of piping. Realign coupling if required by adjusting driver end.

E. Auxiliary Connections.

Connect any auxiliary connections and gauges. Refer to figure 4 for WKM piping plans.

III. OPERATION.

A. Prestart Cautions.

Before starting or operating the pump, read this entire manual, especially the following instructions.

1. Fill pump with water that is at operating temperature. When the temperature stabilizes, recheck coupling alignment according to section II, paragraph B. Drain pump.
2. Lubrication of bearing.

CAUTION

The Timken type TDO bearing (16) on WKM pumps is very sensitive to inadequate lubrication. Oil in bearing housing (99) must be kept at proper level at all times. Operation of the unit without proper lubrication can result in overheating of the bearing, bearing failure, pump seizures and actual breakup of the equipment, exposing operating personnel to injury.

Pumps are shipped with the bearing housings empty of oil. ISO Grade 68 or 100 oil is recommended for proper lubrication of the pump. See table 10A for recommended oil types.

- a. To add oil to bearing housing: Add oil through top port of bearing housing (99) until oil is sighted through view port (143). Continue to add oil through oiler (125) to bearing housing (99) until oiler (125) stabilizes (bubbling stops). Refer to figure 5 for illustration of oiler (125). Inspect oiler (125) on a daily basis to check oil level in bearing housing

- (99). For further details on lubricating the bearings, refer to section V, paragraph A.
- b. To drain old oil from bearing housing: Remove pipe plugs (426) at bottom of inboard bearing cover (35) and bearing housing (99).
3. Observe all caution or danger tags attached to the equipment.
4. Install closed guards around all exposed rotating parts.
5. Rotate shaft by hand to assure all moving parts are free.
6. On packing pumps, check that the nuts securing packing gland are finger tightened only.
7. Never run pump dry because the close running fits within the pump may be lubricated by the fluid being pumped. Dry running may result in pump seizure.
8. Before starting the pump, check for proper priming.
9. Check direction of driver rotation by connecting electrical power supply to motor and "jogging" motor. Direction of rotation should be clockwise when viewed from driver end toward pump.

B. Start Up.

Follow the following procedure to start the pump:

WARNING

Do not operate pump unit against a closed discharge system. If discharge valve is closed and flow of liquid at discharge end is reduced to zero, power absorbed at pump shaft will not drop to zero, but will remain quite appreciable. This will result in heating of liquid trapped inside pump. If pump has any chance of operation against a closed system, a bypass system allowing a minimum of 10% of best efficiency point (BEP) flow should be installed. Continuous minimum flow should be 25% of BEP or higher. See table 1 for minimum flow rates.


Table 1. Minimum Flow Rates

Pump Model	Speed	Minimum Flow
WKM-50	1750 RPM	40 GPM
WKM-50	3500 RPM	65 GPM
WKM-65	1750 RPM	90 GPM
WKM-65	3500 RPM	95 GPM
WKM-80	1750 RPM	150 GPM
WKM-80	3500 RPM	200 GPM


NOTE

For operating temperatures in excess of 212 degrees F, increase flow rates by 25%.


WKM PIPING PLAN NO. 1




WKM PIPING PLAN NO. 2



WKM PIPING PLAN NO. 3



WKM PIPING PLAN NO. 4



- | | | | |
|------------------------|-------------------------|---------------------|----------------------|
| 1 - BALANCE LINE | 3 - BEARING COOLING OUT | 5 - FIRST STAGE | 7 - SEAL COOLING OUT |
| 2 - BEARING COOLING IN | 4 - FLUSH GLAND | 6 - SEAL COOLING IN | |

Figure 4. WKM Piping Plans

CAPACITY: 4 oz.
PIPE THREAD CONN.: 1/4

DIMENSIONS:

- A: $2\frac{5}{16}$
- B MIN.: $4\frac{3}{8}$
- B MAX.: $4\frac{7}{8}$
- C MIN.: $\frac{7}{32}$
- C MAX.: $\frac{23}{32}$

ALL DIMENSIONS
IN INCHES




Figure 5. Trico Type E Oiler, Catalog Number 30054

1. Open suction valve and fill pump completely with fluid.
2. Open discharge valve to allow a minimum of 10% design flow according to table 1.
3. Open valves to auxiliary connections, if applicable.
4. For high temperature design pumps, turn on cooling water to bearing and stuffing box and check to make sure it is flowing freely.
5. If standard design is used and liquid pumped is over 85 degrees F, turn on cooling water to bearings and check to make sure it is flowing freely.
6. Refer to table 2 for cooling water flow requirements for bearing and stuffing box.
7. Start pumping unit.
8. Open discharge valve as required to establish system flow and pressure.
9. It is recommended that the following checks be made and recorded:
 - a. Vibration on motor bearings should not exceed 1 mil displacement at 3500 RPM and 2 mils displacement at 1750 RPM.
 - b. Vibration on pump bearing should not exceed 1 mil displacement at 3500 RPM and 2 mils displacement at 1750 RPM.
 - c. Check motor horsepower (amps and kilowatts). Check all three leads on motor. If amperes vary more than 2%, electrical supply should be checked to prevent damage to motor.
 - d. Make sure pump discharge pressure at prescribed operating speed never drops below 90% of design point pressure.
 - e. Check pressure/vacuum at suction.
 - f. Mechanical seal pumps, check mechanical seal for leakage. Minor leakage usually stops after a short time. If leakage is more than five drops per minute schedule preventative maintenance repair.
 - g. Packing pumps, check stuffing box area for leakage. Leakage should be a steady drip. Refer to section V, paragraph B to adjust leakage.
10. The following is recommended after initial run-in and checks:
 - a. Stop unit.
 - b. Drain system.

- c. Remove strainer from suction piping and any debris found.
- d. Check all hold down bolts and piping connections.
- e. Check coupling alignment as outlined in section II, paragraph B.

C. Stopping the Pump.

1. Begin to partially close discharge valve.
2. Tag out and lock power to driver according to OSHA Standard 1910.147.
3. Completely close discharge and suction valves.
4. If applicable, shut off cooling water.
5. Refer to section V, paragraph D for protective measures to follow if pump is to be shut down for an extended period of time.

D. Operating Checks.

The pump should always run quietly and smoothly, without vibration. To ensure such operation, the following supervision should be carried out at regular intervals during operation of the pump:

Daily:

1. Visually inspect unit.
2. Inspect oiler to check oil level in bearing housing.
3. Check bearing temperatures. Bearing temperatures should not exceed 220 degrees F.
4. Mechanical seal pumps, check for leakage through mechanical seal. If leakage exceeds five drops per minute, schedule preventative maintenance repair.
5. Packing pumps, check stuffing box area for leakage. Leakage should be a steady drip. Refer to section V, paragraph B to adjust leakage.

Weekly:

1. Check horsepower readings.
2. Check vibration.

Monthly:

1. Grease coupling (if applicable). Do not over grease.
2. Check coupling alignment according to section II, paragraph B.

Table 2. Cooling Water Flow Rates

Service	Flow Rate
Less than 85°F	1/2 GPM
85°F to 220°F	1 GPM
Greater than 220°F	1-1/2 GPM

3. Check foundation bolts.

blems do occur, significant time and expense can be saved if you refer to table 3 to eliminate the common causes of those problems.

IV. TROUBLESHOOTING.

If you have followed the installation and starting procedures outlined in this manual, the pump should provide reliable service and long life. However, if operating prob-

Table 3. Troubleshooting Guide

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
Pump does not deliver rated capacity.	1. Excessive pressure in discharge line.	1. Check GPM and head against design conditions; pump may be too small. Consult your local Carver Pump Company office.
	2. Incomplete priming or venting of pump or piping.	2. Prime pump and piping again and vent them.
	3. Suction line or an impeller is clogged.	3. Clean out suction strainer; if necessary dismantle pump and clean impeller.
	4. Positive suction head is too low (on pumps operating with positive suction head).	4. Check liquid level. Check that valves in suction line are fully open, if necessary lock them open to prevent accidental closure. Check that suction line is correctly designed and laid. There should be no features which might cause excessive pressure drop. Clean out line strainers.
	5. Excessive suction lift (on pumps operating on suction lift).	5. Check liquid level and make sure that foot valve is fully open. Clean out if necessary.
	6. Entrapment of air through stuffing boxes.	6. Check external sealing line to make sure it is not clogged.
	7. Reverse rotation.	7. Change direction of rotation. If electrically driven, reverse polarity of motor. Retighten shaft nut if necessary.
	8. Pump speed is too low.	8. On pumps driven by internal combustion engines, adjust governor. On pumps driven by steam turbines, adjust steam turbine governor. On pumps driven by a motor, check voltage and power consumption for motor overload.
	9. Excessive wear of internal parts.	9. Disassemble pump, replace worn components, and reassemble pump.
Driver is overloaded.	1. Pump discharge pressure is lower than design point (check pump nameplate).	1. Partially close discharge valve until pressure at discharge flange is as specified. If driver remains overloaded, decrease speed, if possible, or trim impellers (consult Carver Pump Company before taking this step).

Table 3. Troubleshooting Guide - (Contd.)

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
Driver is overloaded. - (Contd.)	2. Pump is pumping a fluid with specific gravity in excess of that specified (if temperature of fluid is lower than specified, specific gravity will be higher.)	2. If prescribed fluid temperature or specific gravity cannot be attained, one or more of following measure can be taken, if operating conditions permit: a. Partially close discharge valve, reducing pump capacity to a point where driver is not overloaded. b. Remove one or more impellers and their diffusers. c. Trim one or more impellers. d. Install more powerful pump driver. Please consult factory in any event specifying exact operating conditions.
Leakage at casings or cooling water jacket.	1. Tie bolts not sufficiently tightened. 2. O-rings are damaged.	1. Shut down pump, release pressure, and tighten tie bolts evenly after pump has cooled completely. 2. Replace o-rings.
Stuffing boxes leak.	1. Insufficient cooling water, or fouling of cooling water jackets. 2. The pump runs "rough", the shaft chatters. 3. Mechanical seal defective. 4. Freshly packed stuffing box.	1. Remove cooling water jackets; thoroughly clean them. Ensure adequate cooling water supply to cooling water jackets. 2. Check pump bearings, replacing them if necessary. If this does not eliminate trouble, dismantle pump and check shaft for true running, rebalancing entire rotating assembly. Carefully reassemble in accordance with procedures given in section VI, paragraphs F and G. Replace mechanical seal if necessary. 3. Replace mechanical seal. 4. Allow pump to run until leakage stabilizes. Refer to section V, paragraph B.
Bearings run hot.	5. Packing rings are compressed or defective. 1. Pump and motor shafts are misaligned. 2. Piping causes pump to "warp." 3. Over-oiled bearings. 4. Insufficient oil to bearings. 5. Insufficient cooling of oil.	5. Replace packing according to section VI, paragraph I. 1. Check coupling alignment according to section II, paragraph B. 2. Ensure piping transmits no stress to pump. If necessary, alter piping layout. Realign pump, motor shafts. 3. Remove excess oil from bearing housing. 4. Add oil according to section III, paragraph A, step 2. 5. Check cooling water flow rate to bearing house. Refer to section III, paragraph B, step 6.

Table 3. Troubleshooting Guide - (Contd.)

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
<p>Pump discharge pressure excessive.</p>	<ol style="list-style-type: none"> 1. Excessive speed. 2. Specific gravity of fluid pumped is too high (temperature of fluid is lower than specified). 3. Suction pressure too high. 	<ol style="list-style-type: none"> 1. Check speed precisely and: <ol style="list-style-type: none"> a. Decrease speed, if possible. b. Remove one or more impellers and their diffusers. c. Cut back outlet tips of impeller vanes. <p>Please consult factory in any event specifying exact operating conditions.</p> 2. If pump must operate for prolonged periods at low temperatures or high specific gravity, follow suggestions given under "Excessive speed." 3. Check suction pressure.

V. MAINTENANCE.

In addition to the following maintenance procedures, perform regular operating checks in section III, paragraph D.

A. Maintenance of Bearings.

The bearing (16) is mounted in the bearing housing (99), which is fitted onto the suction casing (203). The Timken two-row tapered roller bearing, type TDO, contains a double cup with two single cones and a cone spacer. The heat generated by the tapered roller bearing's surface contact necessitates cooling of the oil. On standard design pumps operating at temperatures below 85 degrees F, fluid being pumped is used as coolant. Coolant is supplied from an outside source on pumps operating at temperatures above 85 degrees F. Refer to section III, paragraph B, step 6 for information on cooling water flow rates.

The bearing (16) is oil lubricated. ISO Grade 68 or 100 oil is recommended for proper lubrication of the bearing. Oil level should be checked on a daily basis and it should be changed every 1000 hours of operation. The Timken bearing is very sensitive to inadequate lubrication. Adequate lubrication with the proper oil type is essential at all times.

To drain old oil from bearing housing: Remove pipe plugs (426) at bottom of inboard bearing cover (35) and bearing housing (99).

To add oil to bearing housing: Add oil through top port of bearing housing (99) until oil is sighted through view port (143). Continue to add oil through oiler (125) to bearing housing (99) until oiler (125) stabilizes (bubbling stops). Refer to figure 5 for illustration of oiler (125). Inspect oiler (125) on daily basis to check oil level in bearing housing (99).

NOTE

It is recommended that bearing be replaced if pump is to be overhauled.

B. Packing Pumps, Stuffing Box Maintenance.

Pumps are delivered with stuffing boxes packed. Packing stuffing boxes will give trouble free service provided that they are carefully and correctly serviced and maintained. A newly packing stuffing box will leak considerably after initial packing or repacking. If this leakage does not stop after the pump has been running a few hours, the gland nuts (615) should be tightened slowly and evenly on either side while the pump is running until the gland (17) only leaks slightly, indicating that it is functioning correctly. If the stuffing box does not leak, or if it starts to smoke, loosen the gland nuts (615) slightly.

NOTE

Every freshly packed stuffing box needs a certain running time before it stabilizes; therefore, close observation at frequent intervals during running-in is important. Once the leakage stabilizes, it need only be checked occasionally.

After prolonged service, or when packing has been compressed by approximately the width of one packing ring, packing should be renewed and condition of shaft sleeve checked. Refer to section VI, paragraph I for packing removal and installation of new packing.

C. Driver Maintenance.

For driver maintenance refer to the driver manufacturer's instruction manual.

D. Indefinite Shutdown.

If pump is to be shut down for an extended period of time (such as a unit used for seasonal operation), the following procedure is recommended:

1. Disconnect coupling.
2. Disconnect or lock off power supply.
3. Block off suction piping.

CAUTION

When pump is handling hazardous fluid, extreme care must be taken to ensure safety of personnel when attempting to drain pump. Suitable protection devices should be used and/or protective clothing should be worn.

CAUTION

It is better to have pump full of liquid than partially full of liquid. The latter will cause accelerated corrosion of wear rings and diffusers, resulting in a 10% drop in capacity during initial operation after restart. However, if there is a possibility of liquid freezing, completely drain casings and all piping.

4. Check liquid level in pump. If there is a possibility of liquid freezing, completely drain casings by removing casing plugs and drain all piping.
5. Check bearing housing oil level.
6. Provide pump and motor with a protective cover.

VI. DISASSEMBLY AND REASSEMBLY.

A. Recommended Tools.

After prolonged operation, it may be difficult to pull components from shaft. In such casings rust solvent may be used and suitable extracting tools applied where possible. Never use force under any circumstances. The following tools are recommended for disassembly and reassembly: bearing puller; spanner wrench; rawhide or wood mallet; wooden wedge (support stage casings); allen wrench set; punch; socket, open, and/or box wrench set; and scribe (for new seal installation).

B. Preparation for Disassembly.

Refer to figure 8, 9, 10, 11, 12, or 13 as applicable for location of parts followed by item number. Follow the following procedure before disassembling the pump:

1. Read this entire section and study figure 8, 9, 10, 11, 12, or 13 as applicable before disassembling the pump.

WARNING

Before attempting to disassemble the pump, the driver controls must be locked and tagged in the OFF position to prevent injury to personnel servicing the pump.

2. Stop the pump according to section III, paragraph C.
3. Close all system valves. Disconnect suction, discharge, and gauge lines.

WARNING

When pump is handling hazardous fluid, extreme care must be taken to ensure safety of personnel when attempting to drain pump. Suitable protective devices should be used and/or protective clothing should be worn.

4. Drain pump by removing drain plugs (422 and 424) from bottom of casings (1, 197, and 203). If pump is high temperature design, remove drain plugs from cooling jacket (215).
5. Drain oil from bearing cover (35) and bearing housing (99) by removing plugs (426).

C. Disassembly.

Refer to figure 8, 9, 10, 11, 12, or 13 as applicable for location of parts followed by item number.

1. Remove coupling guard. Uncouple pump from driver. Pull coupling half off pump shaft (6). Remove coupling key (46).

CAUTION

To lift pumping unit, a hoist or suitable lifting device should be used.

2. Remove capscrews holding pump to base. Remove pump from base and take to a suitable work area.
3. Clamp down discharge casing foot to steady pump during disassembly.
4. Disconnect all male connector retaining nuts from male connector bodies (410, 411, and 412) as applicable. Remove tubing (400 and 408) as applicable. Retaining nuts will remain with tubing.
5. Number and match-mark stage casing(s) so that discharge casing (197), interstage casing(s) (1), and suction casing (203) will be reassembled in correct sequence and position.
6. Support interstage casing(s) (1) before dismantling to prevent them from dropping when suction casing (203) is removed.

NOTE

Pump should be dismantled from discharge (outboard) end. Mark or number each component as it is dismantled according to sequence. **IMPORTANT:** Be aware of any shims between impellers and spacer sleeves, and mark the sequence accordingly. In instances where multiple gaskets are used as shims, note number of gaskets removed so the same number of new gaskets can be installed during reassembly.

7. Remove hex nuts (616). Remove tie bolts (173) connecting discharge casing (197) and suction casing (203).
8. Remove discharge casing (197). End cap (37) and sleeve bearing (18) will be removed along with discharge casing (197). Remove and discard o-ring (89A) on discharge casing (197).
9. Remove bolts (601). Remove end cap (37) from discharge casing (197), using jacking/forcing screws (666) if necessary to loosen rabbet fit. Remove o-ring (89E).
10. Remove capscrew (685). Remove sleeve bearing (18) from discharge casing (197).
11. Remove jam nuts (614) and washer (645) from outboard end of shaft (6).
12. Remove outboard shaft sleeve (14B) from shaft (6).
13. Remove and discard shaft o-ring (89B) from shaft (6).
14. Remove last stage diffuser (5B).
15. On models WKM-50 and WKM-65, remove impeller/sleeve key (32C). On model WKM-80, remove impeller key (32A). Remove last stage impeller (2B).
16. Pry off interstage casing (1) with interstage sleeve (58) and casing o-ring (89D). Remove interstage sleeve (58) and o-ring (89D) from interstage casing (1).
17. Remove diffuser bushing (63), if applicable. Remove diffuser (5A).
18. Remove impeller key (32A). Remove interstage gasket(s) (73G).
19. Remove impeller (2B). Remove interstage gasket(s) (73G).
20. Repeat steps 16 through 19 for each stage.
21. Remove first stage impeller (2A). Remove spacer sleeve (14C).
22. On standard design pumps, remove bolts (600). On high temperature design pump, remove nuts (618) from studs (632). Remove hex nuts (615) from studs (630). Packing pumps, remove split gland (17).
23. Remove bearing housing (99) and shaft assembly from suction casing (203). Remove and discard gland gasket (73F) from gland (17). On high temperature pumps, remove and discard cooling jacket gasket (89C) from suction casing (203).

NOTE

Bearing housing (99) and shaft assembly consists of shaft (6); o-ring (89B); inboard bearing cover (35); bearing lockwasher (69); bearing locknut (22); bearing housing (99); bearing (16); spacer sleeve (14E); slinger (40); shaft sleeve (14A); sleeve key (32B); seal collar (68) and mechanical seal (90) or packing rings (13) and lantern ring(s) (29) as applicable; gland (17); and, if high temperature design, cooling jacket (215), o-ring (89C), and gasket (73C).

24. If high temperature design, remove cooling jacket (215) from outboard end of shaft (6). Remove and discard o-ring (89C) from cooling jacket (215).

NOTE

Mechanical seal pumps, do not remove mechanical seal (90) rotating element from shaft sleeve (14A) at this point, especially if the mechanical seal (90) is relatively clean and is in good working condition. This will simplify reassembly.

25. Mechanical seal pumps, from outboard end of shaft (6), remove seal collar (68) will come off with shaft sleeve (14A). Mechanical seal (90) rotating element and seal collar (68) will come off with shaft sleeve (14A).
26. Packing pumps, remove packing rings (13) and lantern ring(s) (29) as applicable from suction casing (203), shaft sleeve (14), or cooling jacket (215) if high temperature design.
27. Remove sleeve key (32B) from keyway in shaft (6).
28. Mechanical seal pumps, remove gland (17) from shaft (6). Gland (17) contains the stationary element of mechanical seal (90).
29. Remove spacer sleeve (14E), with mounted slinger (40), from shaft (6). Remove slinger (40) from spacer sleeve (14E).
30. Remove hex nuts (617) from studs (631). Remove inboard bearing cover (35) from bearing housing (99). Remove and discard oil seal (71B) from bearing cover (35).
31. Uncrimp locking tab of bearing lockwasher (69). Remove bearing locknut (22) and bearing lockwasher (69).
32. From outboard end of the shaft (6), remove bearing housing (99). Remove and discard o-ring (89F) and oil seal (71A) from bearing housing (99).
33. Carver Pump Company recommends that bearing (16) be replaced if pump is overhauled. Use a puller to remove the bearing (16) from the shaft (6).

D. Parts Cleaning and Inspection.

After disassembly, all parts should be thoroughly cleaned or replaced with new ones if necessary.

After disassembly of the pump, individual parts should be cleaned and inspected as follows:

1. Discard used oil seals, gaskets and o-rings. Packing pumps, discard used packing rings. Thoroughly wash and clean all parts with a suitable solvent.
2. Check shaft (6) for runout, scratches, grooves, or any possible damage. Touch up scratches and grooves with polishing cloth and inspect for remaining grooves or deep scratches. Bent or excessively damaged shaft (6) should be replaced.
3. Mechanical seal pumps, do not remove mechanical seal rotating assembly (80) from shaft sleeve (14A) if the mechanical seal (90) is relatively clean and in good working condition. This will simplify reassembly. If mechanical seal is extremely dirty or damaged, it should be removed and inspected as follows:

NOTE

If mechanical seal (90) is not to be replaced, mark location of seal collar (68) on shaft sleeve (14A).

- a. Loosen, but do not remove, setscrews (665) in seal collar (68). Remove seal collar (68). Remove mechanical seal (90) rotating element from shaft sleeve (14A).
 - b. Remove mechanical seal (90) stationary element from gland (17).
 - c. Check seal bellows or flexible sealing components for signs of deterioration.
 - d. Carefully remove any buildup on sealing faces. Ensure that no dirt, smudges, or flaws remain on sealing faces as this could result in seal failure.
 - e. Inspect rotating seal component or primary ring for possible wear. Inspect stationary seal component for scoring. If there are signs of wear or scoring, the mechanical seal should be replaced.
4. Check all shaft protecting sleeves and spacer sleeves visually for score marks, scratches, pits, or grooves. Touch up sleeves with polishing cloth and inspect for remaining grooves or deep scratches. Shaft protecting sleeves and spacer sleeves should be replaced if any marks, pits, or grooves are still visible after touching up.
 5. Inspect impellers (2A and 2B) for pitting, erosion, or clogged vanes. If impellers (2A and 2B) are damaged in any way, they should be replaced. If new impellers are installed, they must be axially aligned with respect to diffusers. Refer to section VI, paragraph H.

6. Sealing faces should be perfectly clean.
7. Inspect wear ring clearance for each stage as follows:

NOTE

On WKM-50 and WKM-65, wear rings (7A and 7B) appear in the suction casing (203) and each interstage casing (1). On WKM-80, wear rings (7A and 7B) appear in the suction casing (203), each interstage casing (1), and each diffuser (5A and 5B). For WKM-80, impeller "front" hub specifies hub closest to suction end of pump, and impeller "back" hub specifies hub closest to discharge end of pump.

- a. Measure outside diameters of impeller (2A and/or 2B) hubs in three places.
- b. Measure inside diameters of corresponding wear rings (7A and/or 7B) in three places.
- c. Corresponding differences between high readings of inside diameters of wear rings (7A and 7B) and low readings of outside diameters of impellers (2A and 2B) must not exceed clearances specified in table 4.

Table 4. Maximum Wear Ring Clearance for Allowable Wear

Pump Model	Stage	Maximum Diametrical Clearance
WKM-50	All	.038 inches
WKM-65	All	.034 inches
WKM-80	First	.036 inches
WKM-80	Second	.042 inches

- d. If replacement is required, convey applicable casings (1 and/or 203), impellers (2A and/or 2B), and/or, on WKM-80, diffusers (5A and/or 5B) to a work area with access to machine shop equipment. Replace the wear rings (7A and/or 7B) according to section VI, paragraph E.

E. Wear Ring Replacement.

If pump is not already disassembled, perform disassembly procedures outlined in section VI, paragraphs B and C, steps 1 through 21. Take applicable casings, impellers, and/or diffusers to a good machine shop. To replace the wear rings, follow the following procedure:

1. Remove old wear ring (7A and/or 7B) from suction casing (203), stage casing(s) (1), and/or diffuser(s) (5A and/or 5B), as applicable. This can best be accomplished on a lathe.
2. Press new wear ring (7A and/or 7B) in suction casing (203), stage casing(s) (1), and/or diffuser(s) (5A and/or 5B), as applicable.
3. Place impeller (2A and/or 2B) on an arbor and mount between centers in a lathe. Indicate impel-

ler front hub (and/ or impeller back hub on WKM-80) to within .002 T.I.R. maximum to be sure that arbor and impeller (2A and/or 2B) are running square.

4. Turn wearing surface of impeller (2A and/or 2B) until a 63 RMS or better finish is obtained.
5. Measure outside diameter of impeller hub and record.
6. Mount suction casing (203), stage casing (1) and/or diffuser (5A and/or 5B), with new wear ring (7A and/or 7B) inserted , in a lathe. Indicate male rabbet to within .002 T.I.R. maximum.
7. Bore wear ring (7A and/or 7B) to within the specified tolerance listed in table 5 over the recorded size of outside diameter of impeller hub.

Table 5. New Wear Ring Clearance Limits

Pump Model	Stage	Diametrical Clearance
WKM-50	All	.015 to .019 inches
WKM-65	All	.013 to .017 inches
WKM-80	First	.012 to .018 inches
WKM-80	Second	.017 to .021 inches

8. Return impeller (2A and/or 2B) and suction casing (203), stage casing(s) (1) and/or diffusers (5A and/or 5B) to pump assembly. Reassemble pump according to section VI, paragraphs F and G.

F. Preparations for Reassembly.

Coat fits of individual components with suitable lubricant before assembly.

When the pump unit is being overhauled, Carver Pump Company recommends that the following parts be replaced with new:

1. All o-rings. Do not try to substitute inch for metric sizes.
2. All gaskets, ensuring that thickness of new gasket is exactly the same as that of the old one.
3. Timken bearing.
4. Mechanical seal pump, mechanical seal.
5. Packing rings pump, all packing rings.
6. If new impellers or new shaft protecting sleeves are fitted, impellers must be axially aligned with respect to diffuser. Refer to section VI, paragraph H for alignment procedure.

G. Reassembly.

Refer to figure 8, 9, 10, 11, 12 or 13 as applicable for location of parts followed by an item number. Reassemble the pump in accordance with accepted rules of engineering practice. Reassembly of unit should be performed on a flat surface. It is recommended that all nuts and bolts be torqued according to table 6. Ensure components are fitted in correct sequence.

Reassembly commences at the suction (inboard end) of the pump. Follow the following procedure to reassemble the pump:

Table 6. Recommended Torque Values

Size	Torque Value in Foot Pounds
1/4 inch	5 foot pounds
3/8 inch	15 foot pounds
1/2 inch	30 foot pounds
5/8 inch	55 foot pounds
3/4 inch	110 foot pounds
7/8 inch	155 foot pounds
1 inch	275 foot pounds
1-1/8 inch	390 foot pounds

NOTE

Bearings are given a serial number and each cone, cup, and spacer in the bearing is marked with this number. During assembly check the number on each individual part to make sure they all are for the same matched bearing.

NOTE

To ensure proper seating of bearing parts, rotate the bearing while clamping up the parts.

1. Install new oil seal (71A) on shaft. Install new bearing (16) on shaft (6). Carver Pump Company recommends that the bearing's inner and outer cones be heated for easier assembly. Follow the following procedure:
 - a. Install the bearing's inner cone on the shaft (6) and hold the hot cone against the cold shaft shoulder until the cone seizes. The hot cone will pull away from the shoulder unless it is held in position. Compressed air can help speed the cooling.
 - b. Install bearing's cone spacer.
 - c. Install bearing's cup.
 - d. Install bearing's outer cone.
 - e. Use a feeler gauge to make sure inner cone is fully seated against shaft shoulder.
2. Install bearing lockwasher (69) so that tab of lockwasher (69) fits into keyway on shaft (6).
3. Install bearing locknut (22) and tighten against lockwasher (69). Crimp lockwasher tab into slot provided on outside of bearing locknut (22).
4. Install outboard end of shaft (6) in through inboard side of bearing housing (99).
5. Install new lubricated o-ring (89F) in groove provided in bearing housing (99).
6. Install new oil seal (71B) on shaft. Secure inboard bearing cover (35) to bearing housing (99) with hex nuts (617) on studs (631).

7. Install slinger (40) on spacer sleeve (14E). Slide spacer sleeve (14E) onto outboard end of shaft (6), next to shaft shoulder.
8. Insert sleeve key (32B) into keyway in shaft (6). Packing pumps, install o-ring (89B). Mechanical seal pumps, o-ring (89B) will be installed later. Slide shaft sleeve (14A) onto outboard end of shaft (6), lining up keyway of shaft sleeve (14A) with sleeve key (32B).

NOTE

Steps 9 through 14 apply to mechanical seal pumps only. For packing pumps, proceed to step 15.

9. To determine placement of seal collar (68) on shaft sleeve (14A), for installation of mechanical seal (90) rotating element, refer to figure 6A or 6B and follow the following procedure:
 - a. Insert shaft (6) through inboard end of suction casing (203). Standard design, secure bearing housing (99) to suction casing (203) with bolts (600). High temperature design, secure bearing housing (99) to suction casing (203) with nuts (618) on studs (632).
 - b. Scribe a mark on shaft sleeve (14A) corresponding to outer edge of stuffing box in suction casing (203).
 - c. Remove bolts (600) or nuts (618) as applicable. Remove shaft assembly from suction casing (203). Remove shaft sleeve (14A).
 - d. Scribe a second mark on shaft sleeve (14A) at the distance specified in table 7 from the first scribe mark, toward outboard end.

Table 7. Mechanical Seal Settings

Pump Model	Type 21, WKM-50 & WKM-65 Type 1, WKM-80 dimension
WKM-50	1.000 inch
WKM-65	1.000 inch
WKM-80	2.187 inches

- e. Install seal collar (68) immediately to the outboard side of the second scribe mark. Secure seal collar (68) to shaft sleeve (14A) with setscrews (665).
10. Lubricate both gland (17) and mechanical seal (90) stationary element with petroleum jelly or other suitable lubricant. Mechanical seal pumps, insert mechanical seal (90) stationary element into gland (17).
11. Slide gland (17) onto outboard end of shaft (6). As applicable, ensure tap flush lines in gland (17) is positioned so flush lines can be connected.
12. Install o-ring (89B) in groove provided on shaft (6).

13. Lubricate shaft sleeve (14A) with petroleum jelly or silicon spray. Mechanical seal pumps, install mechanical seal (90) rotating element on shaft sleeve (14A) on inboard side of seal collar (68).
14. Slide shaft sleeve (14A) onto outboard end of shaft (6), lining up keyway of shaft sleeve (14A) with sleeve key (32B).
15. Check that wear ring (7A) is in suction casing (203). Install new lubricated o-ring (89D) on suction casing (203).
16. If standard design, install new gland gasket (73F) on stuffing box face of suction casing (203). If high temperature design, install new gland gasket (73F) on inboard face of cooling jacket (215).
17. If high temperature design, install new o-ring (89C) on cooling jacket (215). Install new gasket (73C) on inboard face of suction casing (203). Install cooling jacket (215) on outboard end of shaft (6).
18. Install shaft assembly through inboard side of suction casing (203).
19. If standard design, secure bearing housing (99) to suction casing (203) by tightening bolts (600). If high temperature design, secure bearing housing (99) and cooling jacket (215) to suction casing (203) with hex nuts (618) on studs (632). Mechanical seal pumps, secure gland (17) loosely in place with hex nuts (615) on studs (630). Do not tighten hex nuts (615) down at this point.

NOTE

Packing pumps, packing rings (13) should be inserted individually, with the butt joint of each packing ring (13) offset approximately 90 degrees from the preceding ring (13). The split packing gland (17) may be used to push each ring (13) into position. The packing rings (13) should be pressed lightly against each other by the split packing gland (17). Make sure that the butts of any two adjoining rings (13) do not lie in line. Insert packing rings, leaving a 1/4" gap at end so that the gland will have positive guidance and cannot be tightened askew.

20. Packing pumps, individually install two packing rings (13), lantern ring(s) (29) if applicable, and two additional packing rings (13). Packing pumps, install gland (17) and secure loosely with hex nuts (615) on studs (630). Do not tighten hex nuts (615) down at this point.
21. Slide spacer sleeve (14C) onto outboard end of shaft (6), next to shaft sleeve (14A).
22. Insert impeller key (32A) into key way on shaft (6).

NOTE

Replace the same number of new interstage gaskets (73G) during reassembly that were removed during disassembly.




Figure 6A. Mechanical Seal, WKM-50 and WKM-65 Standard Design




Figure 6B. Mechanical Seal, WKM-80 Standard Design

NOTE

IMPORTANT: Reassemble any shims found during disassembly in correct sequence.

23. Slide interstage gasket(s) (73G) onto outboard end of shaft (6), next to spacer sleeve (14C).
24. Slide first stage impeller (2A) onto shaft (6) from outboard end, fitting keyway of impeller to impeller key (32A) on shaft (6).
25. Slide interstage gasket(s) (73G) onto shaft (6) from outboard end, next to first stage impeller (2A).
26. Slide interstage sleeve (58) onto shaft (6) from outboard end, next to gasket(s) (73G). Install bushing (63) on interstage sleeve (58) if applicable.
27. Slide interstage gasket(s) onto shaft (6) from outboard end, next to interstage sleeve (58).
28. Insert impeller key (32A) into keyway on shaft (6).
29. Check that wear ring (7B) is in interstage casing (1) for WKM-50 or WKM-65. Check that wear ring (7B) is in diffuser (5A) for WKM-80. Install new lubricated o-ring (89D) in groove provided on stage casing (1). Lightly tap diffuser (5A) into stage casing (1). Align diffuser vanes on either side of boss located in stage casing (1).
30. Install stage casing assembly onto shaft (6) and fit onto suction casing (203).
31. Slide next impeller (2B) onto shaft (6).
32. Repeat steps 25 through 31 for each stage.
33. On WKM-50 and WKM-65, insert impeller key (32C) into keyway in shaft (6) before installing last impeller (2B). On WKM-80, insert impeller key (32A) into keyway in shaft (6) before installing last impeller (2B).
34. Install last stage impeller (2B). Slide interstage gasket(s) (73G) onto shaft (6) next to impeller (2B).
35. Install new lubricated o-ring (89B) in groove provided on shaft (6).
36. Slide outboard shaft sleeve (14B) onto outboard end of shaft (6), aligning keyway in sleeve (14B) with impeller key (32C) on WKM-50 and WKM-65 or impeller key (32A) on WKM-80.
37. Install washer (645) on shaft (6) next to outboard shaft sleeve (14B).
38. Install and tighten jam nuts (614) on outboard end of shaft (6).
39. Secure sleeve bearing (18) to discharge casing (197) with capscrews (685), make sure sleeve bearing (18) is seated properly before tightening machine screws (685). Install new lubricated o-ring (89A) in groove provided on discharge casing (197).
40. Install discharge casing (197) on shaft (6).
41. Install tie bolts (173) and hex nuts (616).
42. Install new lubricated o-ring (89E) in groove provided in end cap (37).
43. Secure end cap (37) to discharge casing (197) with bolts (601).
44. Rotate shaft (6) by hand to insure smooth rotation. Mechanical seal pumps, tighten nuts (615) on studs (630) securing gland (17) to suction casing (203).
45. Reinstall pump on base and secure with capscrews.
46. Reinstall coupling key (46). Reinstall coupling half on pump shaft (6).
47. Align coupling as outlined in section II, paragraph B of this manual.
48. Reinstall coupling guard.
49. Reinstall tubing (400 and 408) as applicable. Secure tubing by tightening nuts on male connectors (410, 411, and 412) as applicable.
50. Reconnect suction, discharge, and gauge lines. After connection of piping, smooth rotation of shaft should be checked.
51. Reinstall plugs (422 and 424) at bottom of casings (1, 197, and 203). Reinstall plugs (426). If high temperature design, reinstall plugs in bottom of cooling water jackets (215).
52. Open system valves.
53. Unlock and reconnect electrical power supply to motor. Remove tags. Start pump according to section III, paragraphs A and B of this manual.

H. Axial Alignment of Rotor.

If new parts are fitted during reassembly, such as impellers and/or sleeves, first stage impeller (2A) must be axially aligned with respect to outboard face of suction casing. Each subsequent impeller must be aligned with respect to diffuser.

Refer to figure 7A or 7B. Measure distance "A" or "B" from outboard face of suction casing (203) to inside of first stage impeller's (2A) back shroud. Compare measured distance to dimensions given in table 8. Carver Pump Company recommends that this dimension be within .015 inches. If shimming is required, install shim between impeller and spacer sleeve (14C). For each stage measure distance "A" or "B" from inboard face of diffuser (5A or 5B) to inside of impeller's (2B) back shroud. If shimming is required, install shim between impeller (2B) and interstage sleeve (58).

FOR "A" DIMENSION SEE TABLE 8.




Figure 7A. Axial Alignment of Rotor, WKM-50 and WKM-65

FOR "B" DIMENSION SEE TABLE 8.




Figure 7B. Axial Alignment of Rotor, WKM-80

Table 8. Axial Alignment Control Dimensions

Pump Model	Distance "A" in figure 7A + /- .015	Distance "B" in figure 7B + /- .015
WKM-50	.650 inch	
WKM-65	.769 inch	
WKM-80		.984 inch

I. Packing Pumps, Packing Removal and Installation.

To remove packing and install new packing, follow the following procedure:

1. Disconnect, lock off, and tag power supply to driver.
2. Close all system valves.
3. Remove gland nuts (615). Remove split packing gland (17).
4. Remove packing rings (13) and lantern ring(s) (29), as applicable.
5. Clean stuffing box area and shaft sleeve (14E).

NOTE

The packing rings (13) should be inserted individually, with the butt joint of each packing ring (13) offset approximately 90 degrees from the preceding ring (13). The split packing gland (17) may be used to push each ring (13) into position. The packing rings (13) should be pressed lightly against each other by the split packing gland (17). Make sure that the butts of any two adjoining rings (13) do not lie in line. Insert packing rings, leaving a 1/4" gap at end so that the gland will have positive guidance and cannot be tightened askew.

6. Install new packing rings (13) and lantern ring(s) (29) as applicable, in the same order as they were removed.
7. Install split packing gland (17). Install and lightly tighten gland nuts (615).
8. Open system valves.
9. Unlock and reconnect electrical power supply to motor. Remove tags. Start pump according to section III, paragraphs A and B of this manual.

10. A newly packed stuffing box will leak appreciably at first. If this leakage does not stop after the pump has been running a few hours, the gland nuts (615) should be tightened slowly and evenly on either side while the pump is running until the gland only leaks slightly, indicating that it is functioning correctly. If the stuffing box does not leak, or if it starts to smoke, loosen the gland nuts (615) slightly.

VII. SPARE PARTS.

Spare parts should be on hand for normal service to avoid unnecessary delays for maintenance. Table 9 lists WKM pump components which are recommended as spare parts. When ordering spare parts, be sure to include the part name, item number, serial number and model number of the pump (on pump nameplate), and quantity of parts needed.

Carver may ship an interchangeable part that is not identical in appearance or symbol. This is done only if the part has been improved. Examine the parts carefully on receipt before questioning the factory or representative. Never return parts to the factory without authorization from Carver Pump Company.

If an impeller is ordered, specify the diameter across the blade tips to be sure there was not further trim on the diameter than shown on Carver Pump Company's records.

If a driver or drivers parts are ordered, specify the name of the driver manufacturer and all data on the driver nameplate.

VIII. TECHNICAL DATA.

Technical data is listed in table 10.

IX. PARTS LIST AND DRAWINGS.

Refer to table 11 for the parts list. Refer to figure 8, 9, 10, 11, 12, or 13 as applicable for an illustration.

Table 9. Recommend Spare Parts

ITEM NUMBER	PART NAME	QTY. REQUIRED
2A and 2B	Impeller	As required
7A	Suction Casing Wear Ring	1
7B	Interstage Casing Wear Ring	As required
13	Packing rings (packing pumps)	As required
14A	Shaft Sleeve	1
14B	Shaft Sleeve	1
14C	Sleeve Spacer	1
14E	Sleeve Spacer	1
16	Roller bearing	1
18	Sleeve bearing	1
58	Interstage sleeve	As required
68	Shaft Collar (seal pumps)	1
73C	Gasket(cooling water jacket, high temperature design pumps)	1
73F	Gasket (seal gland)	1
73G	Gasket (interstage sleeve)	As required
89A	O-ring (last stage diffuser)	1
89B	O-ring (sleeve)	2
89C	O-ring (cooling jacket, high temperature design pumps)	1
89D	O-ring (stage casing)	As required
89E	O-ring (end cap)	1
89F	O-ring (bearing cover)	1
90	Mechanical Seal (seal pumps)	1

Table 10. Specifications and Operating Limits

Maximum capacity	2200 GPM
Maximum head	1500 feet
Maximum liquid temperature with standard stuffing box	220 degrees F
Maximum liquid temperature with cooled stuffing box	285 degrees F
Maximum discharge pressure	650 PSI
Maximum suction pressure	150 PSI
Rotation (viewed from driver end)	clockwise
Flange positions (viewed from driver end)	suction - right side discharge - top pointing up

Table 10A. Recommended Oil Types for Bearig Lubrication

MANUFACTURER	ISO GRADE 68	ISO GRADE 100
Royal Purple	Synfilm 68	Synfilm 100
Texaco	Regal R&O 68	Regal R&O 100
Phillips	Magnus 68	Magnus 100
Exxon	Teresstic 68	Teresstic 100
Mobil	DTE 16	DTE 18

Table 11. Parts List

ITEM NO.	PART NAME	QTY.	REMARKS
1	Interstage casing	As reqd.	
2A	Impeller	1	First stage
2B	Impeller	As reqd.	Stage
5A	Diffuser	As reqd.	Stage
5B	Diffuser	1	Last stage
6	Shaft	1	
7A	Wear ring	1	Suction casing
7B	Wear ring	As reqd.	Stage casing
13	Packing ring	As reqd.	Packing pumps
14A	Shaft sleeve	1	Seal or packing, as applicable per pump
14B	Shaft sleeve	1	Sleeve bearing
14C	Sleeve spacer	1	
14E	Sleeve spacer	1	
16	Roller bearing	1	Timken type TDO
17	Gland	1	Seal or packing, as applicable per pump
18	Sleeve bearing	1	
22	Bearing locknut	1	
29	Lantern ring	As reqd.	Packing pumps
32A	Impeller key	As reqd.	
32B	Sleeve key	1	
32C	Impeller key	1	WKM-50 and WKM-65 pumps
35	Bearing cover	1	
37	End cap	1	
40	Slinger	1	
45	Vent	2	
46	Coupling key	1	
58	Interstage sleeve	As reqd.	
63	Diffuser bushing	As reqd.	Optional part used for stainless steel pumps
68	Seal collar	1	Mechanical seal pumps
69	Bearing lockwasher	1	
71A	Oil seal	1	Bearing housing
71B	Oil seal	1	Bearing cover
73C	Gasket	1	Cooling jacket, high temperature design pumps
73F	Gasket	1	Seal gland, mechanical seal pumps
73G	Gasket	As reqd.	Interstage sleeve
89A	O-ring	1	Last stage diffuser
89B	O-ring	2	Sleeve
89C	O-ring	1	Cooling jacket, high temperature design pumps
89D	O-ring	As reqd.	Casing
89E	O-ring	1	End cap
89F	O-ring	1	Bearing cover
90	Mechanical seal	1	Mechanical seal pumps
99	Bearing housing	1	

Table 11. Parts List - (Contd.)

ITEM NO.	PART NAME	QTY.	REMARKS
125	Oiler	1	
143	Viewport	2	
173	Tie bolt	4	
197	Discharge casing	1	
203	Suction casing	1	
215	Cooling jacket	1	High temperature design pumps
400	Tubing	1	Balance line
408	Tubing	1	Seal or packing flush, as applicable per pump
410	Tube connector	As reqd.	
411	Tube connector	As reqd.	
412	Tube connector	As reqd.	WKM-50, WKM-65, and WKM-80 with mechanical seal
422	Pipe plug	As reqd.	Suction casings
423	Pipe plug	As reqd.	Discharge and suction casings on all, bearing housing on WKM-50 and 65
424	Pipe plug	As reqd.	Casing drain
425	Pipe plug	As reqd.	End cap and bearing cover
426	Magnetic pipe plug	As reqd.	Bearing housing
455	Pipe elbow (not shown)	As reqd.	Suction casing
456	Pipe elbow	1	Seal or packing flush, as applicable per pump
600	Bolt	4	Bearing housing, standard design pumps
601	Bolt	8	End cap
614	Jam nut	2	Shaft
615	Hex nut	4	Gland
616	Hex nut	4	Tie bolt
617	Hex nut	4	Bearing cover
618	Hex nut	4	Cooling jacket, high temperature design pumps
630	Stud	4	Gland
631	Stud	4	Bearing cover
632	Stud	4	Cooling jacket, high temperature design pumps
645	Washer	1	Shaft
665	Setscrew	2	Seal collar, mechanical seal pumps
666	Jacking/forcing screw	4	End cap
685	Capscrew	2	Sleeve bearing
975	Dual heat exchanger	1	




Figure 8. WKM High Temperature Design with Mechanical Seal Detail Drawing







Figure 9. WKM High Temperature Design with Packing Detail Drawing



ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	INTERSTAGE CASE	37	END CAP	408	TUBING - SEAL	616	NUT - TIE BOLT
2	IMPELLER - 1ST STG.	38	IMPELLER	410	TUBE CONNECTOR	617	NUT - BRG. COVER
3	IMPELLER	39	KEY - IMPELLER	411	TUBE CONNECTOR	620	TUB - BRG. COVER
4	IMPELLER	40	KEY - IMPELLER	412	PIPE PLUG - SUCT. CASE	621	WASHER - SHAFT
5	DIFFUSER - LAST STG.	41	BEARING COVER	422	PIPE PLUG - SUCT. CASE	624	WASHER - SHAFT
6	SHAFT	42	END CAP	423	PIPE PLUG - BRG. FR. SUCT. & DISCH.	645	SETScrew - SEAL COLLAR
7	WEAR RING - SUCT. CASE	43	IMPELLER	424	PIPE PLUG - CASE DRAIN	646	FORCING SCREW - END CAP
8	WEAR RING - SEAL	44	KEY - IMPELLER	425	PIPE PLUG - END CAP	647	FORCING SCREW - SLEEVE BRG.
9	SLEEVE - SLEEVE - SLV. BRG.	45	KEY - IMPELLER	426	MAGNETIC PIPE PLUG - BRG. HSG.	648	CAPSCREW - SLEEVE BRG.
10	SLEEVE - SPACER	46	KEY - IMPELLER	427	PIPE ELBOW - SUCT. CASE (NOT SHOWN)	649	HEAT EXCHANGER
11	SLEEVE - SPACER	47	IMPELLER	456	PIPE ELBOW - SUCT. FLUSH		
12	ROLLER BEARING	48	IMPELLER	600	BOLT - BRG. HSG. / CASE		
13	GLAND	49	IMPELLER	601	BOLT - ENG. CAP		
14	SLEEVE BEARING	50	IMPELLER	614	NUT - SHAFT		
15	SLEEVE BEARING	51	IMPELLER	615	NUT - GLAND		
16	IMPELLER	52	IMPELLER				
17	IMPELLER	53	IMPELLER				
18	IMPELLER	54	IMPELLER				
19	IMPELLER	55	IMPELLER				
20	IMPELLER	56	IMPELLER				
21	IMPELLER	57	IMPELLER				
22	IMPELLER	58	IMPELLER				
23	IMPELLER	59	IMPELLER				
24	IMPELLER	60	IMPELLER				
25	IMPELLER	61	IMPELLER				
26	IMPELLER	62	IMPELLER				
27	IMPELLER	63	IMPELLER				
28	IMPELLER	64	IMPELLER				
29	IMPELLER	65	IMPELLER				
30	IMPELLER	66	IMPELLER				
31	IMPELLER	67	IMPELLER				
32	IMPELLER	68	IMPELLER				
33	IMPELLER	69	IMPELLER				
34	IMPELLER	70	IMPELLER				
35	IMPELLER	71	IMPELLER				
36	IMPELLER	72	IMPELLER				
37	IMPELLER	73	IMPELLER				
38	IMPELLER	74	IMPELLER				
39	IMPELLER	75	IMPELLER				
40	IMPELLER	76	IMPELLER				
41	IMPELLER	77	IMPELLER				
42	IMPELLER	78	IMPELLER				
43	IMPELLER	79	IMPELLER				
44	IMPELLER	80	IMPELLER				
45	IMPELLER	81	IMPELLER				
46	IMPELLER	82	IMPELLER				
47	IMPELLER	83	IMPELLER				
48	IMPELLER	84	IMPELLER				
49	IMPELLER	85	IMPELLER				
50	IMPELLER	86	IMPELLER				
51	IMPELLER	87	IMPELLER				
52	IMPELLER	88	IMPELLER				
53	IMPELLER	89	IMPELLER				
54	IMPELLER	90	IMPELLER				
55	IMPELLER	91	IMPELLER				
56	IMPELLER	92	IMPELLER				
57	IMPELLER	93	IMPELLER				
58	IMPELLER	94	IMPELLER				
59	IMPELLER	95	IMPELLER				
60	IMPELLER	96	IMPELLER				
61	IMPELLER	97	IMPELLER				
62	IMPELLER	98	IMPELLER				
63	IMPELLER	99	IMPELLER				
64	IMPELLER	100	IMPELLER				
65	IMPELLER	101	IMPELLER				
66	IMPELLER	102	IMPELLER				
67	IMPELLER	103	IMPELLER				
68	IMPELLER	104	IMPELLER				
69	IMPELLER	105	IMPELLER				
70	IMPELLER	106	IMPELLER				
71	IMPELLER	107	IMPELLER				
72	IMPELLER	108	IMPELLER				
73	IMPELLER	109	IMPELLER				
74	IMPELLER	110	IMPELLER				
75	IMPELLER	111	IMPELLER				
76	IMPELLER	112	IMPELLER				
77	IMPELLER	113	IMPELLER				
78	IMPELLER	114	IMPELLER				
79	IMPELLER	115	IMPELLER				
80	IMPELLER	116	IMPELLER				
81	IMPELLER	117	IMPELLER				
82	IMPELLER	118	IMPELLER				
83	IMPELLER	119	IMPELLER				
84	IMPELLER	120	IMPELLER				
85	IMPELLER	121	IMPELLER				
86	IMPELLER	122	IMPELLER				
87	IMPELLER	123	IMPELLER				
88	IMPELLER	124	IMPELLER				
89	IMPELLER	125	IMPELLER				
90	IMPELLER	126	IMPELLER				
91	IMPELLER	127	IMPELLER				
92	IMPELLER	128	IMPELLER				
93	IMPELLER	129	IMPELLER				
94	IMPELLER	130	IMPELLER				
95	IMPELLER	131	IMPELLER				
96	IMPELLER	132	IMPELLER				
97	IMPELLER	133	IMPELLER				
98	IMPELLER	134	IMPELLER				
99	IMPELLER	135	IMPELLER				
100	IMPELLER	136	IMPELLER				
101	IMPELLER	137	IMPELLER				
102	IMPELLER	138	IMPELLER				
103	IMPELLER	139	IMPELLER				
104	IMPELLER	140	IMPELLER				
105	IMPELLER	141	IMPELLER				
106	IMPELLER	142	IMPELLER				
107	IMPELLER	143	IMPELLER				
108	IMPELLER	144	IMPELLER				
109	IMPELLER	145</					




ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	INTERSTAGE CASE	410	TUBE CONNECTOR	600	BOLT - BRG HSG / CASE	617	NUT - BRG COVER
2A	IMPELLER - 1ST STG.	422	PIPE PLUG - SUCT. CASE	601	BOLT - END CAP	620	YIELD POINT
2B	IMPELLER - 2ND STG.	423	PIPE PLUG - BRG. FR. SUCT. & DISCH.	614	NUT - BRG. HSG	631	SLEEVE - BRG. COVER
3A	IMPELLER - 3RD STG.	424	PIPE PLUG - CASE DRAIN	615	NUT - BRG. HSG	645	WASHER - SHAFT
3B	IMPELLER - 4TH STG.	425	PIPE PLUG - END CAP	616	NUT - BRG. HSG	646	FORCING SCREW - END CAP
4	IMPELLER - 5TH STG.	426	PIPE PLUG - SUCT. CASE (NOT SHOWN)	617	NUT - BRG. HSG	655	CAPSCREW - SLEEVE BRG.
5A	IMPELLER - 6TH STG.	427	PIPE ELBOW - SUCT. CASE (NOT SHOWN)	618	NUT - BRG. HSG	656	HEAT EXCHANGER
5B	IMPELLER - 7TH STG.	428	PIPE ELBOW - PACKING FLUSH	619	NUT - TIE BOLT		
6	SHAFT	429	PIPE PLUG - END CAP				
7A	WEAR RING - SUCT. CASE	430	PIPE PLUG - SUCT. CASE (NOT SHOWN)				
7B	WEAR RING - DISCH. CASE	431	PIPE ELBOW - PACKING FLUSH				
7C	IMPELLER - SUCT. CASE	432	VIEWPORT				
7D	IMPELLER - DISCH. CASE	433	TIE BOLT				
7E	IMPELLER - SUCT. CASE	434	DISCHARGE CASE				
7F	IMPELLER - DISCH. CASE	435	SLEEVE - INTERSTAGE				
7G	IMPELLER - SUCT. CASE	436	BUSHING - DIFFUSER				
7H	IMPELLER - DISCH. CASE	437	IMPELLER LOCKWASHER				
7I	IMPELLER - SUCT. CASE	438	OIL SEAL				
7J	IMPELLER - DISCH. CASE	439	SLEEVE - BRG. COVER				
7K	IMPELLER - SUCT. CASE	440	BEARING HOUSING				
7L	IMPELLER - DISCH. CASE	441	OILER				
7M	IMPELLER - SUCT. CASE	442	VIEWPORT				
7N	IMPELLER - DISCH. CASE	443	TIE BOLT				
7O	IMPELLER - SUCT. CASE	444	DISCHARGE CASE				
7P	IMPELLER - DISCH. CASE	445	SLEEVE - INTERSTAGE				
7Q	IMPELLER - SUCT. CASE	446	BUSHING - DIFFUSER				
7R	IMPELLER - DISCH. CASE	447	IMPELLER LOCKWASHER				
7S	IMPELLER - SUCT. CASE	448	OIL SEAL				
7T	IMPELLER - DISCH. CASE	449	SLEEVE - BRG. COVER				
7U	IMPELLER - SUCT. CASE	450	BEARING HOUSING				
7V	IMPELLER - DISCH. CASE	451	OILER				
7W	IMPELLER - SUCT. CASE	452	VIEWPORT				
7X	IMPELLER - DISCH. CASE	453	TIE BOLT				
7Y	IMPELLER - SUCT. CASE	454	DISCHARGE CASE				
7Z	IMPELLER - DISCH. CASE	455	SLEEVE - INTERSTAGE				
8	IMPELLER - SUCT. CASE	456	BUSHING - DIFFUSER				
9	IMPELLER - DISCH. CASE	457	IMPELLER LOCKWASHER				
10	IMPELLER - SUCT. CASE	458	OIL SEAL				
11	IMPELLER - DISCH. CASE	459	SLEEVE - BRG. COVER				
12	IMPELLER - SUCT. CASE	460	BEARING HOUSING				
13	IMPELLER - DISCH. CASE	461	OILER				
14	IMPELLER - SUCT. CASE	462	VIEWPORT				
15	IMPELLER - DISCH. CASE	463	TIE BOLT				
16	IMPELLER - SUCT. CASE	464	DISCHARGE CASE				
17	IMPELLER - DISCH. CASE	465	SLEEVE - INTERSTAGE				
18	IMPELLER - SUCT. CASE	466	BUSHING - DIFFUSER				
19	IMPELLER - DISCH. CASE	467	IMPELLER LOCKWASHER				
20	IMPELLER - SUCT. CASE	468	OIL SEAL				
21	IMPELLER - DISCH. CASE	469	SLEEVE - BRG. COVER				
22	IMPELLER - SUCT. CASE	470	BEARING HOUSING				
23	IMPELLER - DISCH. CASE	471	OILER				
24	IMPELLER - SUCT. CASE	472	VIEWPORT				
25	IMPELLER - DISCH. CASE	473	TIE BOLT				
26	IMPELLER - SUCT. CASE	474	DISCHARGE CASE				
27	IMPELLER - DISCH. CASE	475	SLEEVE - INTERSTAGE				
28	IMPELLER - SUCT. CASE	476	BUSHING - DIFFUSER				
29	IMPELLER - DISCH. CASE	477	IMPELLER LOCKWASHER				
30	IMPELLER - SUCT. CASE	478	OIL SEAL				
31	IMPELLER - DISCH. CASE	479	SLEEVE - BRG. COVER				
32	IMPELLER - SUCT. CASE	480	BEARING HOUSING				
33	IMPELLER - DISCH. CASE	481	OILER				
34	IMPELLER - SUCT. CASE	482	VIEWPORT				
35	IMPELLER - DISCH. CASE	483	TIE BOLT				
36	IMPELLER - SUCT. CASE	484	DISCHARGE CASE				
37	IMPELLER - DISCH. CASE	485	SLEEVE - INTERSTAGE				
38	IMPELLER - SUCT. CASE	486	BUSHING - DIFFUSER				
39	IMPELLER - DISCH. CASE	487	IMPELLER LOCKWASHER				
40	IMPELLER - SUCT. CASE	488	OIL SEAL				
41	IMPELLER - DISCH. CASE	489	SLEEVE - BRG. COVER				
42	IMPELLER - SUCT. CASE	490	BEARING HOUSING				
43	IMPELLER - DISCH. CASE	491	OILER				
44	IMPELLER - SUCT. CASE	492	VIEWPORT				
45	IMPELLER - DISCH. CASE	493	TIE BOLT				
46	IMPELLER - SUCT. CASE	494	DISCHARGE CASE				
47	IMPELLER - DISCH. CASE	495	SLEEVE - INTERSTAGE				
48	IMPELLER - SUCT. CASE	496	BUSHING - DIFFUSER				
49	IMPELLER - DISCH. CASE	497	IMPELLER LOCKWASHER				
50	IMPELLER - SUCT. CASE	498	OIL SEAL				
51	IMPELLER - DISCH. CASE	499	SLEEVE - BRG. COVER				
52	IMPELLER - SUCT. CASE	500	BEARING HOUSING				
53	IMPELLER - DISCH. CASE	501	OILER				
54	IMPELLER - SUCT. CASE	502	VIEWPORT				
55	IMPELLER - DISCH. CASE	503	TIE BOLT				
56	IMPELLER - SUCT. CASE	504	DISCHARGE CASE				
57	IMPELLER - DISCH. CASE	505	SLEEVE - INTERSTAGE				
58	IMPELLER - SUCT. CASE	506	BUSHING - DIFFUSER				
59	IMPELLER - DISCH. CASE	507	IMPELLER LOCKWASHER				
60	IMPELLER - SUCT. CASE	508	OIL SEAL				
61	IMPELLER - DISCH. CASE	509	SLEEVE - BRG. COVER				
62	IMPELLER - SUCT. CASE	510	BEARING HOUSING				
63	IMPELLER - DISCH. CASE	511	OILER				
64	IMPELLER - SUCT. CASE	512	VIEWPORT				
65	IMPELLER - DISCH. CASE	513	TIE BOLT				
66	IMPELLER - SUCT. CASE	514	DISCHARGE CASE				
67	IMPELLER - DISCH. CASE	515	SLEEVE - INTERSTAGE				
68	IMPELLER - SUCT. CASE	516	BUSHING - DIFFUSER				
69	IMPELLER - DISCH. CASE	517	IMPELLER LOCKWASHER				
70	IMPELLER - SUCT. CASE	518	OIL SEAL				
71	IMPELLER - DISCH. CASE	519	SLEEVE - BRG. COVER				
72	IMPELLER - SUCT. CASE	520	BEARING HOUSING				
73	IMPELLER - DISCH. CASE	521	OILER				
74	IMPELLER - SUCT. CASE	522	VIEWPORT				



ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	INTERSTAGE CASE	73G	GASKET - INTSTG. SLV.	411	TUBE CONNECTOR - BALANCE	631	STUD - BRG. COVER
2A	IMPELLER - 1ST STG.	88A	O-RING - 1ST STG. O. DIFF.	412	TUBE CONNECTOR	631	WASHER - SHAFT
2B	IMPELLER - 2ND STG.	88B	O-RING - SLEEVE	422	PIPE PLUG - SUCT. CASE	645	SETSCREW - COLLAR
3A	DIFFUSER	89D	O-RING - CASING	423	PIPE PLUG - SUCT. & DISH	665	FORCING SCREW - END. CAP
3B	DIFFUSER	89E	O-RING - END CAP	424	PIPE PLUG - CASE DRAIN	685	CAPSCREW - SLEEVE BEARING
4	DIFFUSER - LAST STG.	89F	BRG. COVER	425	PIPE PLUG - END CAP	685	HEAT EXCHANGER
6	SHAFT	89F	BRG. COVER SEAL	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
7A	WEAR RING - SUCT. CASE	89G	BEARING HOUSING	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
7B	WEAR RING - SUCT. CASE	89H	BEARING HOUSING	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
8	WEAR RING - SUCT. CASE	125	OILER	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
9	WEAR RING - SUCT. CASE	143	VIEWPORT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
10	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
11	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
12	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
13	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
14	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
15	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
16	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
17	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER
18	WEAR RING - SUCT. CASE	173	TIE BOLT	426	MAGNETIC PIPE PLUG - BRG. HSG.	685	HEAT EXCHANGER

NOTE
BOLT (600) IS FOR STANDARD DESIGN PUMPS ONLY

Figure 12 VKM-80 with Mechanical Seal Sectional Drawing 31/(32 blank)



ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	INTERSTAGE CASE	73G	GASKET - INSTIG. SLV.	411	TUBE CONNECTOR - BALANCE	631	STUD - BRG. COVER	426	MAGNETIC PIPE PLUG - BRG. HSG.
2A	IMPELLER - 1ST STG.	89A	O-RING - LST. STG. DIFF.	422	PIPE PLUG - SUCT. CASE	645	WASHER - SHAFT END CAP	455	PIPE ELBOW - SUCT. CASE (NOT SHOWN)
2B	IMPELLER - 2ND STG.	89B	O-RING - SLEEVE	423	PIPE PLUG - SUCT. & DISH	646	WASHER - IMPELLER END CAP	456	PIPE ELBOW - PACKING FLUSH
3A	DIFFUSER - 1ST STG.	89D	O-RING - CASING	424	PIPE PLUG - CASE DRAIN	648	CARSBREW - SUCT. CASE	600	BOLT - BRG. HSG. - CASE
3B	DIFFUSER - LAST STG.	89E	O-RING - END CAP	425	PIPE PLUG - END CAP	649	PIPE PLUG - SUCT. CASE	601	BOLT - END CAP
4	SHAFT	89F	BRG. COVER	426	MAGNETIC PIPE PLUG - BRG. HSG.	614	NUT - SHAFT	602	WASHER - IMPELLER END CAP
5	WEAR RING - SUCT. CASE	89G	BEARING HOUSING	427	PIPE ELBOW - SUCT. CASE (NOT SHOWN)	615	NUT - GLAND	603	WASHER - IMPELLER END CAP
6	WEAR RING	89H	OILER	428	PIPE ELBOW - PACKING FLUSH	616	NUT - TIE BOLT	604	WASHER - IMPELLER END CAP
7A	PACKING RING	125	VIEWPORT	429	PIPE ELBOW - BRG. HSG. - CASE	617	NUT - BRG. COVER	605	WASHER - IMPELLER END CAP
7B	PACKING RING	143	TIE BOLT	430	PIPE ELBOW - BRG. HSG. - CASE	618	NUT - BRG. COVER	606	WASHER - IMPELLER END CAP
8	SHAFT SLEEVE - PACKING	173	DISCHARGE CASE	431	PIPE ELBOW - BRG. HSG. - CASE	619	NUT - BRG. COVER	607	WASHER - IMPELLER END CAP
9	SHAFT SLEEVE - SLV. BRG.	197	SUCTION CASE	432	PIPE ELBOW - BRG. HSG. - CASE	620	NUT - BRG. COVER	608	WASHER - IMPELLER END CAP
10	SLEEVE - SPACER	203	TUBING - BALANCE	433	PIPE ELBOW - BRG. HSG. - CASE	621	NUT - BRG. COVER	609	WASHER - IMPELLER END CAP
11	SLEEVE - SPACER	400	TUBING - PACKING FLUSH	434	PIPE ELBOW - BRG. HSG. - CASE	622	NUT - BRG. COVER	610	WASHER - IMPELLER END CAP
12	ROLLER BEARING	408	TUBE CONNECTOR	435	PIPE ELBOW - BRG. HSG. - CASE	623	NUT - BRG. COVER	611	WASHER - IMPELLER END CAP
13	GLAND - PACKING	410		436	PIPE ELBOW - BRG. HSG. - CASE	624	NUT - BRG. COVER	612	WASHER - IMPELLER END CAP
14	GLAND - PACKING	411		437	PIPE ELBOW - BRG. HSG. - CASE	625	NUT - BRG. COVER	613	WASHER - IMPELLER END CAP
15	GLAND - PACKING	412		438	PIPE ELBOW - BRG. HSG. - CASE	626	NUT - BRG. COVER	614	WASHER - IMPELLER END CAP
16	GLAND - PACKING	413		439	PIPE ELBOW - BRG. HSG. - CASE	627	NUT - BRG. COVER	615	WASHER - IMPELLER END CAP
17	GLAND - PACKING	414		440	PIPE ELBOW - BRG. HSG. - CASE	628	NUT - BRG. COVER	616	WASHER - IMPELLER END CAP
18	GLAND - PACKING	415		441	PIPE ELBOW - BRG. HSG. - CASE	629	NUT - BRG. COVER	617	WASHER - IMPELLER END CAP
19	GLAND - PACKING	416		442	PIPE ELBOW - BRG. HSG. - CASE	630	NUT - BRG. COVER	618	WASHER - IMPELLER END CAP
20	GLAND - PACKING	417		443	PIPE ELBOW - BRG. HSG. - CASE	631	NUT - BRG. COVER	619	WASHER - IMPELLER END CAP
21	GLAND - PACKING	418		444	PIPE ELBOW - BRG. HSG. - CASE	632	NUT - BRG. COVER	620	WASHER - IMPELLER END CAP
22	GLAND - PACKING	419		445	PIPE ELBOW - BRG. HSG. - CASE	633	NUT - BRG. COVER	621	WASHER - IMPELLER END CAP
23	GLAND - PACKING	420		446	PIPE ELBOW - BRG. HSG. - CASE	634	NUT - BRG. COVER	622	WASHER - IMPELLER END CAP
24	GLAND - PACKING	421		447	PIPE ELBOW - BRG. HSG. - CASE	635	NUT - BRG. COVER	623	WASHER - IMPELLER END CAP
25	GLAND - PACKING	422		448	PIPE ELBOW - BRG. HSG. - CASE	636	NUT - BRG. COVER	624	WASHER - IMPELLER END CAP
26	GLAND - PACKING	423		449	PIPE ELBOW - BRG. HSG. - CASE	637	NUT - BRG. COVER	625	WASHER - IMPELLER END CAP
27	GLAND - PACKING	424		450	PIPE ELBOW - BRG. HSG. - CASE	638	NUT - BRG. COVER	626	WASHER - IMPELLER END CAP
28	GLAND - PACKING	425		451	PIPE ELBOW - BRG. HSG. - CASE	639	NUT - BRG. COVER	627	WASHER - IMPELLER END CAP
29	GLAND - PACKING	426		452	PIPE ELBOW - BRG. HSG. - CASE	640	NUT - BRG. COVER	628	WASHER - IMPELLER END CAP
30	GLAND - PACKING	427		453	PIPE ELBOW - BRG. HSG. - CASE	641	NUT - BRG. COVER	629	WASHER - IMPELLER END CAP
31	GLAND - PACKING	428		454	PIPE ELBOW - BRG. HSG. - CASE	642	NUT - BRG. COVER	630	WASHER - IMPELLER END CAP
32	GLAND - PACKING	429		455	PIPE ELBOW - BRG. HSG. - CASE	643	NUT - BRG. COVER	631	WASHER - IMPELLER END CAP
33	GLAND - PACKING	430		456	PIPE ELBOW - BRG. HSG. - CASE	644	NUT - BRG. COVER	632	WASHER - IMPELLER END CAP
34	GLAND - PACKING	431		457	PIPE ELBOW - BRG. HSG. - CASE	645	NUT - BRG. COVER	633	WASHER - IMPELLER END CAP
35	GLAND - PACKING	432		458	PIPE ELBOW - BRG. HSG. - CASE	646	NUT - BRG. COVER	634	WASHER - IMPELLER END CAP
36	GLAND - PACKING	433		459	PIPE ELBOW - BRG. HSG. - CASE	647	NUT - BRG. COVER	635	WASHER - IMPELLER END CAP
37	GLAND - PACKING	434		460	PIPE ELBOW - BRG. HSG. - CASE	648	NUT - BRG. COVER	636	WASHER - IMPELLER END CAP
38	GLAND - PACKING	435		461	PIPE ELBOW - BRG. HSG. - CASE	649	NUT - BRG. COVER	637	WASHER - IMPELLER END CAP
39	GLAND - PACKING	436		462	PIPE ELBOW - BRG. HSG. - CASE	650	NUT - BRG. COVER	638	WASHER - IMPELLER END CAP
40	GLAND - PACKING	437		463	PIPE ELBOW - BRG. HSG. - CASE	651	NUT - BRG. COVER	639	WASHER - IMPELLER END CAP
41	GLAND - PACKING	438		464	PIPE ELBOW - BRG. HSG. - CASE	652	NUT - BRG. COVER	640	WASHER - IMPELLER END CAP
42	GLAND - PACKING	439		465	PIPE ELBOW - BRG. HSG. - CASE	653	NUT - BRG. COVER	641	WASHER - IMPELLER END CAP
43	GLAND - PACKING	440		466	PIPE ELBOW - BRG. HSG. - CASE	654	NUT - BRG. COVER	642	WASHER - IMPELLER END CAP
44	GLAND - PACKING	441		467	PIPE ELBOW - BRG. HSG. - CASE	655	NUT - BRG. COVER	643	WASHER - IMPELLER END CAP
45	GLAND - PACKING	442		468	PIPE ELBOW - BRG. HSG. - CASE	656	NUT - BRG. COVER	644	WASHER - IMPELLER END CAP
46	GLAND - PACKING	443		469	PIPE ELBOW - BRG. HSG. - CASE	657	NUT - BRG. COVER	645	WASHER - IMPELLER END CAP
47	GLAND - PACKING	444		470	PIPE ELBOW - BRG. HSG. - CASE	658	NUT - BRG. COVER	646	WASHER - IMPELLER END CAP
48	GLAND - PACKING	445		471	PIPE ELBOW - BRG. HSG. - CASE	659	NUT - BRG. COVER	647	WASHER - IMPELLER END CAP
49	GLAND - PACKING	446		472	PIPE ELBOW - BRG. HSG. - CASE	660	NUT - BRG. COVER	648	WASHER - IMPELLER END CAP
50	GLAND - PACKING	447		473	PIPE ELBOW - BRG. HSG. - CASE	661	NUT - BRG. COVER	649	WASHER - IMPELLER END CAP
51	GLAND - PACKING	448		474	PIPE ELBOW - BRG. HSG. - CASE	662	NUT - BRG. COVER	650	WASHER - IMPELLER END CAP
52	GLAND - PACKING	449		475	PIPE ELBOW - BRG. HSG. - CASE	663	NUT - BRG. COVER	651	WASHER - IMPELLER END CAP
53	GLAND - PACKING	450		476	PIPE ELBOW - BRG. HSG. - CASE	664	NUT - BRG. COVER	652	WASHER - IMPELLER END CAP
54	GLAND - PACKING	451		477	PIPE ELBOW - BRG. HSG. - CASE	665	NUT - BRG. COVER	653	WASHER - IMPELLER END CAP
55	GLAND - PACKING	452		478	PIPE ELBOW - BRG. HSG. - CASE	666	NUT - BRG. COVER	654	WASHER - IMPELLER END CAP
56	GLAND - PACKING	453		479	PIPE ELBOW - BRG. HSG. - CASE	667	NUT - BRG. COVER	655	WASHER - IMPELLER END CAP
57	GLAND - PACKING	454		480	PIPE ELBOW - BRG. HSG. - CASE	668	NUT - BRG. COVER	656	WASHER - IMPELLER END CAP
58	GLAND - PACKING	455		481	PIPE ELBOW - BRG. HSG. - CASE	669	NUT - BRG. COVER	657	WASHER - IMPELLER END CAP
59	GLAND - PACKING	456		482	PIPE ELBOW - BRG. HSG. - CASE	670	NUT - BRG. COVER	658	WASHER - IMPELLER END CAP
60	GLAND - PACKING	457		483	PIPE ELBOW - BRG. HSG. - CASE	671	NUT - BRG. COVER	659	WASHER - IMPELLER END CAP
61	GLAND - PACKING	458		484	PIPE ELBOW - BRG. HSG. - CASE	672	NUT - BRG. COVER	660	WASHER - IMPELLER END CAP
62	GLAND - PACKING	459		485	PIPE ELBOW - BRG. HSG. - CASE	673	NUT - BRG. COVER	661	WASHER - IMPELLER END CAP
63	GLAND - PACKING	460		486	PIPE ELBOW - BRG. HSG. - CASE	674	NUT - BRG. COVER	662	WASHER - IMPELLER END CAP
64	GLAND - PACKING	461		487	PIPE ELBOW - BRG. HSG. - CASE	675	NUT - BRG. COVER	663	WASHER - IMPELLER END CAP
65	GLAND - PACKING	462		488	PIPE ELBOW - BRG. HSG. - CASE	676	NUT - BRG. COVER	664	WASHER - IMPELLER END CAP
66	GLAND - PACKING	463		489	PIPE ELBOW - BRG. HSG. - CASE	677	NUT - BRG. COVER	665	WASHER - IMPELLER END CAP
67	GLAND - PACKING	464		490	PIPE ELBOW - BRG. HSG. - CASE	678	NUT - BRG. COVER	666	WASHER - IMPELLER END CAP
68	GLAND - PACKING	465		491	PIPE ELBOW - BRG. HSG. - CASE	679	NUT - BRG. COVER	667	WASHER - IMPELLER END CAP
69	GLAND - PACKING	466		492	PIPE ELBOW - BRG. HSG. - CASE	680	NUT - BRG. COVER	668	WASHER - IMPELLER END CAP
70	GLAND - PACKING	467		493	PIPE ELBOW - BRG. HSG. - CASE	681	NUT - BRG. COVER	669	WASHER - IMPELLER END CAP
71	GLAND - PACKING	468		494	PIPE ELBOW - BRG. HSG. - CASE	682	NUT - BRG. COVER	670	WASHER - IMPELLER END CAP
72	GLAND - PACKING	469		495	PIPE ELBOW - BRG. HSG. - CASE	683	NUT - BRG. COVER	671	WASHER - IMPELLER END CAP
73	GLAND - PACKING	470		496	PIPE ELBOW - BRG. HSG. - CASE	684	NUT - BRG. COVER	672	WASHER - IMPELLER END CAP
74	GLAND - PACKING	471		497	PIPE ELBOW - BRG. HSG. - CASE	685	NUT - BRG. COVER	673	WASHER - IMPELLER END CAP
75	GLAND - PACKING	472		498	PIPE ELBOW - BRG. HSG. - CASE	686	NUT - BRG. COVER	674	WASHER - IMPELLER END CAP
76	GLAND - PACKING	473		499	PIPE ELBOW - BR				

X. Pump Service Record

Serial No. _____ Size and Type _____ Make _____

Cust. Order No. _____ Date Installed _____

Install. Date	Location	Application

PUMP RATING

Capacity (GPM) _____ Total Head (ft) _____

Suction Pressure _____ Speed (RPM) _____

Liquid _____ Temperature _____

Specific Gravity _____ Viscosity _____

Impeller Diameters (list all stages in inches) _____

PUMP MATERIALS

Interstage Casing (1) _____ 1st Stage Impeller (2A) _____ Impeller (2B) _____

Diffuser (5A) _____ Diffuser (5B) _____ Shaft (6) _____

Wear Ring (7A) _____ Wear Ring (7B) _____ Bearing Housing (99) _____

Discharge Casing (197) _____ Suction Casing (203) _____ Shaft Nut (614) _____

Mechanical Seal (90) or Packing Rings (13) _____

MOTOR DATA

Motor _____ Make _____ Serial No. _____

Type _____ Frame _____ AC or DC _____

Volts _____ Phase _____ Cycles _____

HP _____ RPM _____

Notes on Inspection and Repairs

Inspect Date	Repair Time	Repairs	Cost	Remarks

Notes: _____



CARVER PUMP COMPANY
2415 Park Avenue ● Muscatine, Iowa 52761-5691
Phone (563) 263-3410 ● Main Fax (563) 262-0509
Marketing Fax (563) 262-0510
E-Mail: carverpump@ muscanet.com
WEB: www.carverpump.com



CARVER PUMP COMPANY
2415 Park Avenue ● Muscatine, Iowa 52761-5691
Phone (563) 263-3410 ● Main Fax (563) 262-0509
Marketing Fax (563) 262-0510
E-Mail: carverpump@muscanet.com
WEB: www.carverpump.com

February 2000
